

CCR

PROCESS PRODUCTS

SR5 Power Supply/Controller Manual



CCR
Process Products

200 Terrence Matthews Crescent Kanata, Ontario, K2M2C6 Canada
Tel: 613-723-3386 Fax: 613-723-9160

Revised May 2011

Warranty and Repair Policy

1. CCR Process Products or as hereinafter referred to as CCR, warrants that its instruments shall be free from defects in material and workmanship for one year under normal and proper use when correctly installed.
2. Any CCR product which proves defective in material or in workmanship within one year from date of shipment by CCR, will be repaired or replaced free of charge provided that (1) buyer provides CCR with satisfactory proof of the defect and that the product was properly installed, maintained, and operated within the limits of rated and normal usage; (2) buyer obtains from CCR authorization to return the product; and (3) products claimed to be defective must be returned with transportation charges prepaid. Product will be returned to Buyer with transportation charges collect unless the item is found to be defective, in which case CCR will pay the return transportation charges.
3. The remedy set forth herein does not apply to damage to or defects in any product caused by the Buyer's misuse or neglect, nor does it apply to any product which has been repaired or disassembled, which in the sole judgement of CCR affects the performance of the product.
4. CCR makes no warranty concerning components not manufactured by it. However, in the event of the failure of any component or accessory not manufactured by CCR, reasonable assistance will be given to Buyer in obtaining from the respective manufacturer whatever adjustment is reasonable based on the manufacturer's own warranty. CCR expressly disclaims any liability to its customers, dealers, and representatives, and to users of its products, and to any other person for special or consequential damages of any kind and from any cause whatsoever arising out of or in any way connected with the manufacture, sale, handling, repair, maintenance, or replacement arising out of or in any way connected with the use of said products.
5. Representations and warranties made by any person, including dealers and representatives of CCR, which are inconsistent or in conflict with the terms of this warranty (including but not limited to the limitations of the liability of CCR, as set forth above), shall not be binding upon CCR unless reduced to writing and approved by an officer of CCR.

THIS EXPRESS WARRANTY SUPERCEDES ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE.

OBTAINING SERVICE UNDER WARRANTY

Advance authorization is required before any product is returned to CCR. Prior to the return of any product, write or call the Repair Department at CCR advising them of; (1) a part number; (2) a serial number of the defective product; (3) a technical description of the defect including specific test data, written observations on the failure and specific corrective action required; (4) a no-charge purchase order number (so the product can be returned to sender correctly); and (5) ship and bill addresses. Non-verified problems or defects may be subject to an evaluation charge. Please return the original calibration data with the unit.

REPAIR WARRANTY

All repairs of CCR products are warranted for a period of 90 days from date of shipment. This warranty applies only to those items which were found defective and repaired. It does not apply to products in which no defect was found and returned as is or merely recalibrated. Out of warranty products may not be capable of being returned to the exact original specifications.

TABLE OF CONTENTS

DESCRIPTION and SPECIFICATIONS 3

INSTALLATION and WIRING 4

SWITCH and FUNCTION DEFINITIONS7

OPERATING INSTRUCTIONS12

CALIBRATION INSTRUCTIONS15

RS232 SERIAL COMMUNICATIONS17

FIGURES

Figure 1 Model SR5 Front Panel View 5

Figure 2 Model SR5 Rear Panel View 5

Figure 3 Transducer Wiring6

Figure 4 Input/Output (I/O) Wiring6

DESCRIPTION

The SR5 is a microprocessor-based digital indicator capable of interfacing directly to a mass flowmeter, a mass flow controller, pressure controller or pressure transducer. A integrated +/-15 vdc @250ma power supply is available providing a well regulated, short circuit and thermal overload protected output. It is packaged in a small 1/8 DIN, 5.5" deep extruded aluminum housing which provides excellent EMI/RFI shielding and good heat dissipation characteristics.

The SR5 is a state-of-the-art product and uses the latest surface mount components. The internal microprocessor provides the following capabilities.

Pushbutton Zero and Full Scale Calibration
Front Panel Setup of Setpoint Control Voltage
Front Panel Setup of (2) High and (2) Low Digital Setpoints with open collector outputs.


SPECIFICATIONS

Signal Input:	0-5 vdc or 0-10 vdc
Input Resistance:	> 1 Megohm
Input Bias Current:	< 1 na
Display Type:	0.4" high efficiency red LED's
Max display range:	+/- 99,999 counts
A/D Resolution:	+/- 19,999 counts
Linearity:	+/- 0.01% FS +/- 1 count
FS Accuracy:	+/-0.01% FS +/- 1 count
FS Step Response:	500ms (typ)
Overrange Display:	Flashing digits for input > 10.5 vdc
No Sensor Indication:	Flashing digits
Setpoint Output:	0-5 vdc or 0-10 vdc (optional)
Power Supply:	+/- 15 vdc +/- 5% @ 250 ma (min)
Operating range:	-10 to +50 degC
Input Power:	100, 110, 220 and 240 VAC (solder pad jumper selectable)
Pkg dimensions:	3.78W x 1.89H x 5.13D
RS232	Optional

INSTALLATION AND WIRING

INSTALLATION

The SR5 enclosure is designated for panel mounting in a 1/8 DIN cutout. The cutout dimensions are shown below.



To panel mount the unit, perform the following steps.

1. Rotate the four pawl screws (outside screws in each corner) several turns counter-clockwise to retract the pawls. Make sure the pawls retract enough to clear the back of the mounting panel. The pawls may be retracted to accomodate panel thicknesses up to 0.25 inches (6.35mm).
2. Insert the instrument into the panel cutout.
3. Position the pawls so that their elongated dimension overlaps the panel cutout, then tighten the screws. Do not over-tighten.
4. Installation complete.

WIRING

Reference Figures 3 and 4 for TRANSDUCER and INPUT/OUTPUT (I/O) wiring information. Power is applied with a 3-prong AC power cord. The instrument is protected by a 250V, 500ma, slo blo, 5mm fuse. The fuse holder is an integral part of the input power connector. A spare fuse is provided in the fuse holder. Internal solder jumpers are provided to allow 100, 110, 220 or 240VAC operation.




Figure 1. SR5 Front Panel View




Figure 2. SR5 Model Rear Panel View




Figure 3. Transducer Wiring Diagram





Figure 4. I/O Wiring Diagram

SWITCH AND FUNCTION DEFINITIONS

SWITCH DEFINITIONS



A) Mode Switch (S1)

The Mode switch (S1) is used to cycle through the various setpoints, hysteresis, calibration values and decimal point locations. The sequence is as follows. The designators, in parenthesis, identify text that will be displayed, momentarily, followed by the value.

Setpoint for Flow	(StPt)
Set Point High 1	(SPH1)
Set Point Low 1	(SPL1)
Set Point High 2	(SPH2)
Set Point Low 2	(SPL2)
Hysteresis High	(HH)
Hysteresis Low	(HL)
Cal	(CAL)
Decimal Point	(dP)
Exit	

While in the Mode Selection sequence, the indicator is no longer monitoring the input signal. To exit at any time, simply depress S4 or cycle through the menu. All new data entered prior to exiting, except StPt, will be stored in non-volatile memory and recalled at power on. Depending on the position of switch SWd, the StPt value may be retained or not upon power cycling (see pg. 9 for details).

B) Increment Switch (S2)

This switch increments the flashing digit. Note that the most significant digit for StPt may be turned off (zero cannot be selected). While updating this digit the display will toggle through the following digits: 1, 2, 3, 4, 5, 6, 7, 8, 9, Blank (first digit will show blank instead of zero).

SWITCH DEFINITIONS (cont)

C) Step and Min-Max Switch (S3)

This switch has a dual function. When in the MODE sequence, it steps the digit to be incremented, one position to the right. Using S3 in conjunction with S2 allows rapid updating of all parameter values.

When not in the MODE sequence, depressing S3 displays the HI (Max) and LO (Min) readings, momentarily. These values are stored in static RAM and are reset when power is applied. When power is applied, the maximum value is initialized to -99,999 and the minimum value to 99.999.

The HI and LO values are the maximum and minimum values, respectively, of the displayed readings. Sign and magnitude are constantly compared with the displayed readings at the instrument update rate of 2.5 times per second.

D) Zero and Exit Switch (S4)

This switch has a dual function. When **not** in the MODE sequence, this switch must be depressed and held for approximately 3 seconds before it zeroes the reading on the display. The ZERO annunciator on the front panel should be illuminated. ZEROing is accomplished by storing the reading just prior to ZEROing and subtracting this value from all subsequent readings. This value is retained in non-volatile memory and recalled when power is applied. It is also used to compensate the StPt control voltage output so that the input equals the setpoint even though display is zeroed.

When in the MODE sequence, this switch is used to exit. All values entered prior to exiting, except for the StPt value (see ****NOTE**), will be retained in non-volatile memory and recalled when power is applied.

E) Cal Switch (S5)

Note, user must understand cal process fully prior to activating this process. This switch must be depressed and held for approximately 3 seconds to auto-calibrate the readout. When initially held and depressed for 3 seconds the CAL annunciator will extinguish and the display will read the raw data generated by the analog-to-digital converter. When depressed and held again for 3 seconds the CAL annunciator will illuminate and the raw data will automatically be scaled to the CAL value entered previously. (Reference the FS CAL pg 10 and the CALIBRATION INSTRUCTIONS on pg 15 for more information).

FUNCTION DEFINITIONS (cont)

The Mode switch (S1) cycles through the following functions.

a) Setpoint (StPt)

The Setpoint (0-5 vdc or optional 0-10vdc) command signal is used to control the flow through a mass flow controller or pressure controller.

The setpoint output is defined as (for 0-5 vdc):

$$\text{Setpoint Output} = \text{StPt} / \text{CAL} \times 5.000 \text{ vdc} \pm \text{Voffset}$$

where Voffset = Output Offset voltage (Zero)

Example: If the CAL value was programmed to be 7500 sccm and the desired flow rate is 5000 sccm, enter 5000 for the StPt value. Depress the ZERO switch to exit the MODE sequence and the Setpoint Output voltage will be 3.333 vdc. This is assuming the Flowmeter output had no offset voltage.

*****Note: If switch SWd (Reference drawing on pg 17) is ON , the last StPt value will be recalled at power-up, although the StPt display will always display to 0000 at power-up and may not correspond to the actual StPt value.
If Switch SWd is OFF, the StPt output will be zero at power-up.***

b) Set Point High 1 (SPH1)

SPH1 is a digital setpoint being constantly compared with the displayed reading. If the magnitude and sign of the reading *exceeds* the SPH1 value, the SPH1 open collector output will activate and pull its respective D-Sub connector pin to ground (Ref Figure 4 on pg 4). The front panel LED (H1) will also illuminate. If SPH1 is exceeded, the reading must then drop below SPH1 less the Hysteresis High (HH) value before the open collector output opens and the H1 LED turns off.

c) Set Point Low 1 (SPL1)

SPL1 is another digital setpoint being constantly compared with the displayed reading. If the magnitude and sign of the displayed reading *is less than* the SPL1 value, the SPL1 open collector output will activate and LED (L1) will illuminate. If the displayed reading drops below SPL1, it must then exceed SPL1 plus the Hysteresis Low (HL) value before the

FUNCTION DEFINITIONS (cont)

d) Set Point High 2 (SPH2)

SPH2 is independent and functions identically to SPH1. SPH2 has its own open collector outputs and front panel LED (H2).

e) Set Point Low 2 (SPL2)

SPL2 is independent and functions identically to SPL1. SPL2 has its own open collector outputs and front panel LED (L2).

f) Hysteresis High (HH)

HH is the hysteresis value for SPH1 and SPH2. The hysteresis value determines the number of counts the displayed reading must fall below SPH1 and SPH2 values before deactivating their respective open collector outputs and LEDs. The maximum value of hysteresis is 99 counts while the minimum is 00 counts.

g) Hysteresis Low (HL)

HL is the hysteresis value for SPL1 and SPL2. The hysteresis value determines the number of counts the displayed reading must exceed the SPL1 and SPL2 values before deactivating their respective open collector outputs and LEDs. The maximum value of hysteresis is 99 counts while the minimum is 00 counts.

h) FS Cal (CAL)

This input allows the user to calibrate the full scale readout to any desired engineering units. This input must be entered prior to performing the calibration. For best resolution and stability, choose a CAL number between 0500 and 20,000 counts.

Example: If the Flowmeter is to be calibrated at a full scale flowrate of 500 sccm, the FS Cal value could be 500.00, 500.0 or 0500. If the FS Cal value of 500.00 is used, the unit will automatically count by 3 when full scale calibration is completed since the analog-to-digital converter resolution is only 19,999 counts. Choosing a FS Cal value of 500.0 or 0500 assures the best resolution and stability in this particular case.

When changing this CAL number, calibration must subsequently be completed for the SR5 to use this new setting (see p.15).

FUNCTION DEFINITIONS (CONT)

i) Decimal Point (dP)

dP allows selection of decimal point locations for display. The locations selectable are x.xxxx, xx.xxx, xxx.xx, xxxx.x and xxxxx.

OPERATING INSTRUCTIONS


TURN-ON INSTRUCTIONS

Reference Figures 3 and 4 for proper input and output signal wiring.

1. Apply power to the instrument.
2. Verify the instrument readout blanks momentarily, then displays the value of the input signal.
3. To clear the StPt register, depress the MODE(S1), then the ZERO (S4) switch prior to using the instrument.

PROGRAM INSTRUCTIONS

Five front panel switches (S1, S2, S3, S4 and S5) allow the user to program Flowmeter Setpoint Output Voltage (StPt), Digital Setpoints (SPH1, SPL1, SPH2 and SPL2), Hysteresis (HH and HL), Calibration Number (CAL) and Decimal Points (dP) and monitor minimum, maximum or real time values.



1. Depress MODE (S1) switch once.

The text **StPt** will be displayed momentarily followed by the current value for the Flowmeter Setpoint. Use switches S2 and S3 to set the StPt value. Proceed to Step 2 to set Set Point H1 (SPH1) or depress S4 to exit the MODE sequence. If S4 is depressed the latest StPt value is used to generate a new Flowmeter Setpoint output voltage.

Note StPt setting only applies to mass flow controller or pressure controller and not with a pressure transducer or other type of meter with no valve.

PROGRAM INSTRUCTIONS (cont)

2. Depress MODE (S1) switch once.

The text **SPH1** followed by the current value of Set Point High 1 (SPH1) will be displayed. Use S2 and S3 to set Set Point High 1 to the desired value. Proceed to Step 3 to set Setpoint Low 1 (SPL1) or depress S4 to exit MODE sequence. If S4 is depressed, the new value for SPH1 will be saved in non-volatile NOVRAM memory.

3. Depress MODE (S1) switch once.

The text **SPL1** followed by the current value of Set Point Low 1 will be displayed. Use S2 and S3 to set Set Point Low 1 to the desired value. Proceed to Step 4 or depress S4 to exit.

4. Depress MODE (S1) switch once.

The text **SPH2** followed by the current value of Set Point High 2 will be displayed. Use S2 and S3 to set Set Point High 2 to the desired value. Proceed to Step 5 or depress S4 to exit.

5. Depress MODE (S1) switch once.

The text **SPL2** followed by the current value of Set Point Low 2 will be displayed. Use S2 and S3 to set Set Point Low 2 to the desired value. Proceed to Step 6 or depress S4 to exit.

6. Depress MODE (S1) switch once.

The text **HH** followed by the current value of Hysteresis High will be displayed. Use S2 and S3 to set Hysteresis High to the desired value. The maximum value for HH is 99 counts. Proceed to Step 7 or depress S4 to exit.

PROGRAM INSTRUCTIONS (cont)

7. Depress MODE (S1) switch once.

The text **HL** followed by the current value of Hysteresis Low will be displayed. Use S2 and S3 to set Hysteresis Low to the desired value. The maximum value for HL is 99 counts. Proceed to Step 8 or depress S4 to exit.

8. Depress MODE (S1) switch once.

The text **CAL** followed by the current CAL number will be displayed. Use S2 and S3 to set the CAL number. Proceed to Step 9 or depress S4 to exit.

9. Depress MODE (S1) switch once.

The text **dP** followed by the current decimal position will be shown flashing. Use S2 to set the decimal point to the desired location.

10. Depress MODE (S1) switch once.

The instrument will exit the Mode Selection Sequence and enter the normal operating mode (i.e. monitoring the input signal) This is the end of the PROGRAM INSTRUCTIONS.

CALIBRATION INSTRUCTIONS

Prior to connecting the SR5 to the Mass Flow Controller or other instrument, verify that the controller's ± 15 vdc requirement is no more than 250 ma. The SR5 is capable of supplying up to 500ma for short periods of time (in 1/2 or 1 hour increments). Consult the factory if the current requirement is > 250 ma for prolonged periods of time.

Connect the SR5 to a voltage source with an accuracy of 0.01% or better per Figure 3. The voltage source should be connected between J1-2 and J1-12. Apply AC power to the SR5. Verify that the SR5 lights up and the instrument is displaying a stable reading. If no display appears after 1 or 2 seconds has elapsed, remove the ac power and check the fuse contained in the AC Power Connector at the rear of the SR5 (Reference Figure 2 on pg 5).

If a stable display appears, (allow 15-30 minutes power-up for the SR5 to stabilize,) then perform the calibration procedure shown below.

1. The FS Cal (CAL) value must be entered prior to performing this calibration procedure. Reference pg 8 to enter the FS Cal (CAL) value.
2. Apply zero vdc to the SR5.
3. Depress and hold the ZERO (S4) switch for approximately 3 seconds (Reference Figure 1 on pg 5). Verify ZERO annunciator LED is illuminated and the display reads 0000 \pm 0001 counts. Ignore the decimal point. The SR5 is now zeroed.
4. Apply full scale signal, for example 5.000 vdc \pm 0.0005 vdc to the SR5 (use the same voltage as the maximum signal of the transducer).
5. Depress and hold CAL(S5) switch for approximately 3 seconds. Verify FS CAL annunciator LED is extinguished.


CALIBRATION INSTRUCTIONS (cont)

6. Depress and hold CAL (S5) again for approximately 3 seconds. The FS CAL LED should illuminate and the readout should display the FS Cal value within +/- 1 digit which will correspond to the voltage being input.
7. The CALIBRATION sequence is now complete.

NOTE: Calibration information (zero and scale factor values) are stored in non-volatile memory and are updated every time calibration step 6 above is performed. ZEROing the display changes and stores a new zero value but does not affect the scale factor value.

RS232 SERIAL COMMUNICATIONS

The Parity(Even or None) and the Baud Rate (2400 or 9600) are selectable by setting DIP switches **SWa** and **SWb**, accessible from the right side of the instrument case. **SWc** is utilized for Pressure Controller applications only (0-10 vdc selection). **SWd** turns StPt memory ON or OFF (Reference StPt Function Definition on pg 9).



Parity (SWa)	Baud Rate (SWb)	Stpt Voltage (SWc)	Stpt Memory (SWd)
ON = Even OFF = None	ON = 2400 OFF = 9600	On = 5 V Off = 10V	On= Memory On Off= Memory Off

Baud Rate: Programmable for 2400 or 9600 Baud
Parity: Programmable for Even or None
Data Bits: For Even Parity (7 data bits)
For Odd Parity (8 data bits)
Stop Bits: One
Delimiter: CrLf (Carriage Return-Line Feed)

Command Syntax

Notes: In the following tables, each command or request element separated with square brackets [] is for clarity only.

Unless Otherwise Specified

[value] is indicated as % of full scale and takes the following form: signxxx.xx

When entering commands, unless a minus sign is included, value will be accepted as positive.

When responding to a request, value will contain a +/- sign followed by a number complete to two decimal places.

[counts] will represent an actual number within a defined range.

RS232 SERIAL COMMUNICATIONS

SET COMMAND PROTOCOL

FUNCTION

[Z] [CR] [LF]	Zero the displayed reading
[F] [CR] [LF]	Calibrate Full Scale (Input voltage signal is scaled to display Full Scale)
[S] [counts] [CR] [LF]	Set Full Scale display value. (counts range = 0 99999)
[D] [value] [CR] [LF]	Set decimal position 1 = x.xxxx 2 = xx.xxx 3 = xxx.xx 4 = xxxx.x 5 = xxxxx
[P1] [value] [CR] [LF]	Set level of Lo Alarm #1
[P2] [value] [CR] [LF]	Set level of Lo Alarm #2
[P3] [value] [CR] [LF]	Set level of Lo Alarm #3
[P4] [value] [CR] [LF]	Set level of Lo Alarm #4
[H1] [counts] [CR] [LF]	Set Lo Alarms #1&2 hysteresis
[H2] [counts] [CR] [LF]	Set Hi Alarms #1&2 hysteresis
[X] [counts] [CR] [LF]	Set analog setpoint (range 00000 to 99999)

READ COMMAND PROTOCOL

FUNCTION

RETURN MESSAGE

[R5] [CR] [LF]	Signal Input value	[P] [value] [CR] [LF]
[R8] [CR] [LF]	Full Scale display	[S] [counts] [CR] [LF]
[R9] [CR] [LF]	Decimal location 1 = x.xxxx 2 = xx.xxx 3 = xxx.xx 4 = xxxx.x 5 = xxxxx	[D] [value] [CR] [LF]
[R1] [CR] [LF]	Lo Alarm #1 level	[P1] [value] [CR] [LF]
[R2] [CR] [LF]	Hi Alarm #1 level	[P2] [value] [CR] [LF]
[R3] [CR] [LF]	Lo Alarm #2 level	[P3] [value] [CR] [LF]
[R4] [CR] [LF]	Hi Alarm #2 level	[P4] [value] [CR] [LF]
[R6] [CR] [LF]	Lo Alarm #1&2 hysteresis	[H1] [counts] [CR] [LF]
[R7] [CR] [LF]	Hi Alarm #1&2 hysteresis	[H2] [counts] [CR] [LF]
[RX] [CR] [LF]	Setpoint value	[X] [counts] [CR] [LF]

SERIAL LOCKOUT:

The SR5 will respond to RS-232 commands and queries while it is in the normal display mode. When it is in the menu entry or calibration modes it will not respond to RS-232 commands or queries.